

Digital Panelmeter SPE 670 - 035


Meas. Type: Analog Signals 0-10V/0-20mA
 Dimension Display: on request
 Display/ Rate: 3_Digits / 2.5 Meas./s
 Display Type: LED 12.5mm, red
 Polarity: Auto., "-" sign
 Decimal Point: Programmable
 Protection Index: IP50, DIN 40050
 Operating Temp.: -10°C...+50°C
 Connector Type: Lift clamp
 Front Panel: DIN 48 x 96
 Mounting Depth: D = 115mm
 Panel Cut-out: H x W = 44.5x90.5mm
 Supply: 230V 50-60Hz 4.5VA
 Meas. Ranges: Set by jumper
 Front keys: Lockable by jumper
 Sensor Supply: 24V / 30mA DC

Measuring Ranges

Analog Signals
 Accuracy: ± 0.1%, ±1 Digit of meas.val.

I	0 - 1V	Ri 1 MOhm
I	0 - 10V	Ri 10 MOhm
II	0 - 20mA	Ri 10 Ohm
II	4 - 20mA	Ri 10 Ohm

Setting the Ranges




Measuring Range is freely settable through jumpers at the right side of the device housing.

Jumper A Meas. Range 0 – 10V / 0 – 1V
 Jumper B Meas. Range 0 – 20mA / 4 – 20mA

Attention: Either set Jumper A or Jumper B
 Other combinations may lead to serious damages of the device. Jumpers may not be changed while the device is being connected to power.

Operation Instruction:



- enter or leave programming mode
- increment selected digit
- select next digit / position


Error indications:

If the measuring signal exceeds or falls short of the allowed measuring range the LED display shows:

"oooo" = Measuring range exceeded
 "uuuu" = Measuring range fallen short


Reset to default device setting:

Turn off power. Push simultaneously the leftmost three keys. Hold and turn on power. Release keys after 3 seconds.



Key Lock:
 The jumper is placed on the main board and is accessible from the side of the device housing. By removing the jumper the keys are locked.

Terminal Legend:



- Input 1:** In-HI Voltage range 0 – 10V
- Input 2:** In-HI Voltage range 0 – 1V
- Input 3:** In-HI Current Range 0 – 20mA/4 - 20mA
- Input 4:** GND for all measuring ranges
- Opt.RS232:** Galvanic separated RS232 output GND(11), RXD(10), TXD(9)
- Output:** 24V, 30mA galvanic separated voltage supply for external sensors
- 230V AC:** AC Power input (15,17) or Optional 12V / 24V DC supply input

Option: 12V / 24V DC Supply

In derivation of the standard model the device can be ordered for following auxiliary supply voltages: 12V DC or 24V DC (Conn. 15 "-", 17 "+"). For these models the 24V / 30mA sensor supply voltage is not available. Using this option measurements for up to 200V DC / AC can be performed only since the DC-DC converter isolates 500V. Special DC-DC Converter are available on request for higher measurements.

Option: RS232 with Real Time Clock

The RS232 module with Real Time Clock provides a printer output via the serial interface. Data, Time and Measuring values with dimension are available. The isolated RS232 interface is bi-directional and comes with a driver software. Models 670/... can be controlled external via this interface. (See description on back page)

Option: Analog Output Terminal 9, 11

Models -010 / -020 / -030 / -050 / -060

Output:
 Terminal 9 = + V -1999 digits generate = 0V
 Terminal 11 = GND ±000 digits generate = +5V
 1999 digits generate = +10V
 With this option the 24V voltage supply is not available

CE-Guidelines

Meets the EMV Guideline (89/336/EWG) and the German EMV ruling by applying the Basic Standard EN 50080/ EN 50081. Meets the Low Voltage Guideline (73/23/EWG) by applying Product Standard EN 61010.

Safety Precautions

Employing these instruments, regulations for working with high voltage equipment, as well as any Professional Trade Association regulation for working with electrical appliances and installations have to be observed.

Guarantee Regulations:

Regulations by law apply for guarantee within 12 month. All equipment is factory tested and calibrated. Excluded from the guarantee are normal wear and tear, defects due to misuse, negligence, chemical exposure, mechanical stress as well as equipment, which has been modified, re-labeled or otherwise altered or if attempts to repair have been made. All guarantee claims are subject to our scrutiny and approval.

Service

We are glad that you decided on an instrument from our product range. If there are what so ever any defects, please send the instrument (postage paid) to your distributor.

For technical information contact us via E Mail
 Info@schwille.de

Technical changes reserved.
 Edition: 02.May 2003

Programming:

The programmable Panel Meter 670-XXX with its integrated measuring routines can be controlled by a variety of parameters for the measuring cycle. New values can be entered as on a pocket calculator via keyboard, easy and comfortable.

This is how to select a measuring routine:



Push MOD to enter programming mode



Select routine number with increase key



Push MOD again to confirm selection

To change value on selected routine:



Enter desired value with increase key



Select next position with shift key,

decimal point of selected digit is blinking



Select value with increase key




Enter inserted value

The device now works again in the measuring mode.

Integrated Programming Routines

Routine 1 – 4: Special Measuring Range only

With routines 1-4 the relation between the measuring range and the display range is set. Thereby the slope of the line between start and end values as well as a zero-offset value can be set. To access these routines parameter 1 must be set in Routine 23..



Routine 1: Start of measuring range

Routine 2: Start of display range

Routine 3: End of measuring range

Routine 4: End of display range

Example: Measuring Range: 0 - 1000
 Display Range: 0 - 780
 - Routine 23 set to 1
 - Routine 1 set to 000
 - Routine 2 set to 000
 - Routine 3 set to 1000
 - Routine 4 set to 780

Routine 5: Setting the Options

DAC (Analog Output) or
 RS232 / Real Time Clock board mounted
 000 = DAC or no extension board
 001 = RS232 / RTC board

Routine 6: Setting the Decimal Point Setting the position of the comma on the LED display

- 000 = No decimal point (default)
 - 001 = 1.999
 - 002 = 19.99
 - 003 = 199.9

Routine 19: Viewing Maximum measuring value retention
Routine 20: Viewing Minimum measuring value retention
 The maximum and minimum measuring values since the last reset are continuously recorded and stored. These values can be reset while the min. or max. value is displayed by pushing and holding keys [\wedge] and key [<] simultaneously.

Routine 21: Rounding the last digit The last digit can be rounded to 0, 2 or 5.

Setting: 000 = last digit will be set to 0
 001 = last digit will be displayed (default)
 002 = 2 / 4 / 6 / 8
 003 = 0 / 5 / 0

Routine 22: Setting the number of measurements to generate an average value The average measuring value will be displayed.

Setting: 000 = no average value generation (default).
 002 – 1999 number of measuring cycles used to generate an average value

Routine 23: Selection of measuring method

Setting: 000 = standard measuring (default)
 001 = special measuring range.
 Routines 1 – 4 can be accessed

Routine 25: Activation und Time setting for RS232

Interface
 Setting: 000 = no measurement output (default)
 001 = output activated, cycle time Minutes
 002 = output activated, cycle time Seconds

Data format: 4800 Bd, no Parity, 1 Stop bit and 8 Data bits

Routine 26: Measurement division by 10

Setting: 000 = no division (default)
 001 = measuring value divided by 10

Routine 27: Setting the Baud Rate of the RS232 interface

Setting: 0 = 150,
 1 = 300,
 2 = 600,
 3 = 1200,
 4 = 2400
 5 = 4800,
 6 = 9600 Baud

Setting the Real Time Clock (RTC)

Routine 28: Minutes

This value sets the actual time in minutes
 Setting range: 0 – 59 minutes

Routine 29: Hours

This value sets the actual time in hours
 Setting range: 0 – 23 hours

Routine 30: Day of date

This value sets the actual day of the date
 Setting range: 1 – 31

Routine 31: Day of week

This value sets the actual day of the week
 Setting: 0 = Sunday, 1 = Monday, 2 = Tuesday,
 3 = Wednesday, 4 = Tuesday, 5 = Friday,
 6 = Saturday

Routine 32: Month of date

This value sets the actual month of the date
 Setting range: 1 – 12
 1 = January, 2 = February ... 12 = December

Routine 33: Year of date

This value is least significant part of the year number of the actual year of date. The most significant part is set to 20.
 Setting range: 0 – 99
 0 = 2000,
 99 = 2099

Routine 34: Setting the Transmission cycle for serial interface Date and time are added to the measuring value at the time interval of the programmed transmission cycle and transmitted via the serial interface. The time distance of transmissions is entered in minutes Note that transmission must be activated first either through Routine 25 or through Jumper 4 (see description further down).

Setting range: 0 – 255

0 = Timer Stop (no transmission)
 1 = transmission occurs every minute
 2 = every 2 minutes
 255 = every 255 minutes (4h 15min)

The amount of transmission cycles also effects the transmission of the measuring values if Jumper 4 is closed. If the parameter is set to 0 transmission is stopped. Dimensioning measurements The dimension of a physical unit consists mainly of two parts, the size and the type of the unit. Dimensions are not displayed on the SPE 670 series but appear on the printout. The dimension size and type can be entered in ASCII-code as a decimal value. For the extended character-set code page 437 (IBM) applies.

Routine 35: Size of dimension

Sets the size of the physical unit for the displayed measuring value: m = Milli, μ = Micro, p = Pico ...
 $^{\circ}$ = Grad. Examples: $^{\circ}$ = 248, μ = 230, m = 109,
 n = 110, p = 112, k = 107, M = 77, G = 71.

Routine 36: Type of dimension

Sets the type of the physical unit for the displayed measuring value: V = Volt, A = Ampere ... C = Celsius
 Examples: A = 65, C = 67, V = 86, \ddot{U} = 234 (Ohm).

Routine 37: Customizing signs for measurements

Covering a wider variety of naming measuring values a third sign can be entered. Through this feature names like "Bar" are possible. In this example enter B = 66 in Routine 35, a = 65 in Routine 36 and r = 114 in Routine 37.
 For character translation see ASCII-code table or IBM code page 437.

Jumper 4 Single or event triggering

If Jumper 4 is set measuring values are transmitted at programmed time intervals via the serial interface, even if the interface is deactivated through Routine 25. The transmission cycle is set through Routine 34 respectively can be stopped. Jumper 4 is accessible on the main board left hand side of the display unit. (seen from the front view)